
PROSHOWER PROFILE FRONT is a satin-finish stainless steel AISI 304/1.4301-V2A profile. It is suitable to cover and decorate the visible part of wall in front of the shower tray in case of floor level showers with slope.


PROSHOWER PROFILE FRONT

SATINED STAINLESS STEEL AISI 304 / 1.4301 - V2A


SATINED STAINLESS STEEL AISI 304/1.4301-V2A
degreased and passivated - **thermo packed** - Pack. **1 Pc**

Article	H mm	H1 mm	L cm
PSHWPFACS 101028	10	28	100
PSHWPFACS 101038	10	38	100
PSHWPFACS 101048	10	48	100
PSHWPFACS 101528	10	28	150
PSHWPFACS 101538	10	38	150
PSHWPFACS 101548	10	48	150
PSHWPFACS 1251028	12,5	28	100
PSHWPFACS 1251038	12,5	38	100
PSHWPFACS 1251048	12,5	48	100
PSHWPFACS 1251528	12,5	28	150
PSHWPFACS 1251538	12,5	38	150
PSHWPFACS 1251548	12,5	48	150







PSHWPFACS 101028
PSHWPFACS 101528




PSHWPFACS 1251028
PSHWPFACS 1251528




PSHWPFACS 101038
PSHWPFACS 101538




PSHWPFACS 1251038
PSHWPFACS 1251538



PSHWPFACS 101048
PSHWPFACS 101548



PSHWPFACS 1251048
PSHWPFACS 1251548



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1. Choose "PROSHOWER PROFILE FRONT" according to the desired length. **2.** Cut "PROSHOWER PROFILE FRONT" to the desired length and apply the adhesive on the support where the profile will be laid. **3.** Press the anchoring flange of "PROJOLLY SQUARE" into the adhesive. **4.** Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile. **5.** Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile. **6.** Insert the sheet of glass and seal.

PROSHOWER PROFILE WALL Profile in satin-finish stainless steel AISI 304 / 1.4301 – V2A. It is suitable to cover and decorate the visible part of wall beside the shower tray in case of floor level showers with a slope of 2%.

PROSHOWER PROFILE WALL

SATINED STAINLESS STEEL AISI 304 / 1.4301 - V2A


SATINED STAINLESS STEEL AISI 304/1.4301-V2A - RIGHT
degreased and passivated - **thermo packed** - Pack. **1 Pc**


Article	H mm	H1 mm	H2 mm	L cm
PSHWPLACS 1010DX	10	10	28	100
PSHWPLACS 1015DX	10	10	38	150
PSHWPLACS 1020DX	10	10	48	200
PSHWPLACS 12510DX	12,5	10	28	100
PSHWPLACS 12515DX	12,5	10	38	150
PSHWPLACS 12520DX	12,5	10	48	200

SATINED STAINLESS STEEL AISI 304/1.4301-V2A - LEFT
degreased and passivated - **thermo packed** - Pack. **1 Pc**


Article	H mm	H1 mm	H2 mm	L cm
PSHWPLACS 1010SX	10	10	28	100
PSHWPLACS 1015SX	10	10	38	150
PSHWPLACS 1020SX	10	10	48	200
PSHWPLACS 12510SX	12,5	10	28	100
PSHWPLACS 12515SX	12,5	10	38	150
PSHWPLACS 12520SX	12,5	10	48	200










PSHWPLACS ...SX





PSHWPLACS ...DX





EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1. Choose "PROSHOWER PROFILE WALL" according to the desired length. **2.** Cut "PROSHOWER PROFILE WALL" to the desired length and apply the adhesive on the support where the profile will be laid. **3.** Press the anchoring flange of "PROJOLLY SQUARE" into the adhesive. **4.** Lay the tiles, aligning them with the profile leaving a 2 mm joint. Remove immediately all remains of adhesive from the surface of the profile. **5.** Fill the joints between the profile and the tiles with grout, in order to avoid water stagnation. Remove immediately all the remains of grout from the surface of the profile. **6.** Insert the sheet of glass and seal